



# Custom Dynamics® SXS Horn Kit with Bracket Installation Instructions

We thank you for purchasing the Custom Dynamics® SXS Horn Kit with Bracket. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Number: CD-HORN-SXS**

### Package Contents:

- 6" Cable Ties (6)
- Cable Tie Mounts (4)
- SXS Horn Harness with Switch (1)
- Horn Y-Harness (1)
- Dual Electromagnetic Horn (Horn, Flat Brackets and Nut) (1)
- Dual Horn Cowbell Bracket (1)



**Fitment: Universal 12v System**

### **Installation:**

1. Disconnect the negative battery cable. Refer to your owners manual if unsure of the process.
2. The Horn labeled with "H" is the High. The Horn Labeled with "L" is the Low. Connect the long black (-) wire and long red (+) wire of the Horn Y-harness to the High tone horn terminals. Reference Figure 3 on Page 2.
3. Mount both Dual Electromagnetic Horns to the Dual Horn Cowbell Bracket using the supplied nuts. The High tone Horn will mount on the left side and the Low tone Horn will mount on the right side. Reference orientation of the Horns in Figure 1. **Note:** the Flat Brackets included with the horns will not be used.
4. Connect the remaining black (-) and red (+) wires of the Horn Y-Harness to the Low Horn. Reference Figure 3 on Page 2. **Note:** make sure that the female spade connectors that are connected to the horns do not touch the Dual Horn Cowbell Bracket; bend the horn's male spade connectors *slightly* if necessary.




## ATTENTION

Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.




**Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST**

## Installation Instructions - Page 2

### Installation Continued:

5. Mount the Dual Horn Cowbell Bracket to the vehicle.
6. Mount SXS Horn Harness Switch. The dimensions for the Switch are shown in Figure 2.
7. Route wire "A" from the battery to the dash. Connect the female terminal of wire "A" to terminal 2 on the SXS Horn Harness Switch. Refer to Figure 3.
8. Connect the female terminal of wire "B" to Terminal 3 on the Switch. Refer to Figure 3.
9. Route wire "B" from Terminal 3 on switch of the towards the Horn. Connect to the red wire (+) on Horn Y- Harness. Refer to Figure 3.
10. Route wire "C" from the Negative battery post towards the horn. Connect to the black (-) wire on Horn Y-Harness. Refer to Figure 3.
11. Secure all wiring to prevent the wire from becoming pinched or damaged with the provided Cable Ties and Cable Tie Mounts.
12. Connect the ring terminal from harness "A" to the positive battery post. Refer to Figure 3.
13. Connect the ring terminal from harness "C" and Negative battery cable to the negative battery post. Refer to Figure 3.
14. Test the Dual Electromagnetic Horn for proper operation before riding.




### 3

#### Optional Switch Illumination (wiring not included)

Terminal 8 & 7: Ground

Terminal 6: Switched 12 V +



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-