

PROBEAM®

BY CUSTOM DYNAMICS®

ProBEAM® Sequential Saddlebag LED Lights Installation Instructions

We thank you for purchasing the Custom Dynamics® ProBEAM® Sequential Saddlebag LED Lights. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support. If you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: PB-SBSEQ-HD-BR PB-SBSEQ-HD-BS
PB-SBSEQ-HD-CR PB-SBSEQ-HD-CS

Package Contents:

- ProBEAM® Sequential Saddlebag LED Lights (2)
- HD Y Harness Adapter w/ Plugs (1)
- Isopropyl Alcohol Wipe (1)
- 4" Cable Tie (10)
- Tie Wrap Holder (6)

Fits: 1997-2013 Harley-Davidson® Touring Models with OEM Hard Saddle Bags (**Except** 2010-2013 FLHX, 2010-2013 FLTRX, 2010-2012 FLHXSE2, 2012-2013 FLTRXSE, 2013 FLHRSE5, 2013 FXSBSE).



Installation:

1. Test fit the ProBEAM® Sequential Saddlebag Lights on each bag. The light should mount a couple millimeters below the bottom edge of the lid when the lid is closed. Mark the location with a grease pencil.
2. Using the included Isopropyl Alcohol Wipe, clean the surface area that LEDs will adhere to and allow to dry.
3. Remove the red adhesive backing and install the lights on the left and right saddle bags. Press firmly into place.
4. Remove both bags from the bike.
5. Clean the surface area locations for the tie wrap holders and using the supplied Isopropyl Alcohol Wipe and allow to dry. Remove paper backing from the cable tie holders and press into place (see picture below).
6. Route wires from bag lights to each cable tie holder and secure with tie wraps.
7. Remove seat from bike. Locate rear lighting harness.
8. Plug HD harness adapter into rear wiring harness.

Note: If installed, the order of modules should be Smart Signal Stabilizer™/load equalizer, brake strobe, **Y harness adapter** then run/brake/turn module.

9. Reinstall saddlebags on the bike.
10. Route saddlebag light wires to the Y harness adapter. (Secure with tie wraps)
11. Connect 4 pin plugs from bag lights to Y harness adapter. Female with purple wire plugs into male with purple wire and female with brown wire plugs into male with brown wire.
12. Secure wires with the included cable ties, make sure wiring will not come in contact with moving parts or in an area with high heat. Also take care that wires will not get pinched or frayed.
13. Reinstall the seat and test operation of running, brake and turn signal lights.



ATTENTION

Please read all Information below before Installation

Disclaimer: Removal of our saddlebag lights after installation, may cause permanent damage to the finished surface area of the saddlebag.

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Note: The Y Harness Adapter must be plugged into the output (behind) any Smart Signal Stabilizer™/load equalizer or any brake strobe modules.

Note: The Y Harness Adapter must be plugged into the input (in front) of any run/brake/turn module.



BAGZ™ come with plug and play weatherproof quick disconnect to make future removal of saddlebags quick and easy (see pictures below).



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST