



Custom Dynamics® Micro Turn Signal Adapter Installation Instructions

We thank you for purchasing the Custom Dynamics® Micro Turn Signal Adapter. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: MPR-MICROAW-3AMP

Package Contents:

- Micro Turn Signal Adapter (2)

Fits: 2012-2017 Harley-Davidson® Dyna Models



Installation:

1. Remove the seat and disconnect the negative battery cable from the battery.
2. Locate and remove the left and right frame grommet from the backbone of the frame, just behind the neck.
3. Carefully pull the bikes wiring harnesses out of the frame grommet holes and locate the front turn signal connectors on the main wiring harness. The bikes wiring harnesses runs through the backbone of the frame, from under the seat area and out the frame grommet holes. It may be necessary to feed the bikes wiring harness from under the seat while carefully pulling the wiring harnesses out of the frame grommet holes.
4. Disconnect the front turn signal lighting harnesses from the main harness. Connect one of the Micro Turn Signal Adapter harnesses in-line with the bike's front RIGHT turn signal lighting harness and the main harness. Connect one of the Micro Turn Signal Adapter harnesses in-line with the bike's front LEFT turn signal lighting harness and the main harness.
5. Connect the Micro Turn Signals (Sold Separately) to the installed Micro Turn Signal Adapters.
6. Carefully pull the bikes wiring harness back into the backbone of the frame and reinstall the frame grommets.
7. Secure wires to prevent the wires from becoming cut, frayed, or pinched.
8. Reconnect the negative battery cable to the battery and reinstall the seat.
9. Test operation of all lighting before riding.



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Always wear appropriate safety gear including safety glasses when performing any electrical work. It is highly recommended that safety glasses be worn throughout this installation process. Be sure vehicle is on level surface, secure and cool.

Important: This product is designed and intended for use as auxiliary lighting only. It is NOT intended to replace any original equipment lighting installed on the vehicle and should not be used for that purpose. This product must be wired so that it does not interfere with any original equipment lighting.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST