




## Custom Dynamics® Turn Signal Decoder Installation Instructions

We thank you for purchasing the Custom Dynamics® Turn Signal Decoder. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

**Part Numbers:** GEN-TSD

**Package Contents:**

- Turn Signal Decoder (1)
- Posi-Tap™ (2) Attached



**Fits:** 2014-2024 Harley-Davidson® Ultra Limited (FLHTK), 2014-2023 Street Glide (FLHX), Street Glide Special (FLHXS), 2015-2023 Road Glide (FLTRX), Road Glide Special (FLTRXS), 2017-2024 Road King Special (FLHRXS), 2022-2023 CVO™ Road Glide Limited (FLTRKSE), 2020-2024 Road Glide Limited (FLTRK), 2014-2019 Electra Glide Ultra Classic (FLHTCU), 2015-2016 Ultra Classic Lo (FLHTCUL), 2016-2019 Road Glide Ultra (FLTRU), 2015-2018 Ultra Limited Lo (FLHTKL), 2016 CVO™ Road Glide Ultra (FLTRUSE) and 2016-2021 CVO™ Limited (FLHTKSE).

**Installation:**

1. Remove the seat and locate connector for rear wiring harness.
2. Unplug connector and plug in Turn Signal Decoder, female of the Turn Signal Decoder to the male of the bike's wiring harness and the male of the Turn Signal Decoder to the female of the rear wiring harness.
3. Using the provided Posi-Taps™, attach positive wire of the turn signals to the purple and brown wires :  
  
Purple - Left Turn  
  
Brown - Right Turn
4. Connect the negative wire of the turn signals to a suitable ground connection.
5. Check operation of all lights.
6. Re-install seat.



### ATTENTION



Please read all Information below before Installation

**Warning:** Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

**Safety First:** Make sure the bike is parked on a level surface and bike's mechanical components are cool to the touch.

**Posi-Tap™**  
TAP CONNECTOR

- TAPS WIRES WITHOUT CUTTING
- TOTAL WIRE INTEGRITY IS MAINTAINED
- INSTALLS IN SECONDS BY HAND
- NO CRIMPING OR TOOLS REQUIRED
- REUSABLE OR PERMANENT
- LESS RESISTANCE
- VIBRATION PROOF
- FULLY INSULATED

POWERS UP TO (4) LEADS AT ONCE!

**QUICK & EASY**

- 1 Insert Hot Wire
- 2 Tighten
- 3 Strip Leads
- 4 Insert & Tighten

**NO CRIMPING**

**NO TOOLS NEEDED**