

# PROBEAM®

BY CUSTOM DYNAMICS®

CD #: PB-FB-BCM-KIT

We thank you for purchasing the Custom Dynamics® ProBEAM® BCM COMPLIANT FLAT BEZEL TURN SIGNAL CONVERSION KIT (1156 REAR, 1157 FRONT) LED turn signals! Our LEDs offer maintenance free service and higher visibility. Our ProBEAM® product line utilizes the latest technology and automotive grade components to ensure the highest level of reliable service. Custom Dynamics® offers one of the best warranty programs and customer support in the industry. If you have any questions during the installation of this product please call us at 1(800) 382-1388.

## Package Contents:

- ProBEAM® Front 1157 LED Turn Signal Inserts
- ProBEAM® Rear 1156 LED Turn Signal Inserts
- Choice of Chrome or Black ProBEAM® Flat Bezel Turn Signal Adapters

## Fitment:

Plug & Play on 2011-2017 Softail® Heritage & 2014-2019 Road King® models with Flat style (2 screw) 1156 rear turn signals (models with center taillight). Does NOT Fit CVO™ Models or Road King Special.



## ATTENTION

Please read all Information below before Installation

## Note:

- Use care in removing the OEM lens and bulbs from the housing, so as not to scratch or mar the chrome housing. Custom Dynamics® is not liable for damage to chrome housing during installation.
- Dielectric grease does not need to be used with this LED product, it can actually prevent them from working. Remove any excess grease from your turn signal sockets before inserting.

**\*\*\*IMPORTANT\*\*\***

This LED product is BCM compliant. However, you must run the 4 way hazard flashers for 3 minutes with ignition switch in the "OFF" position to allow the BCM to sync the new LED turn signals after they are installed.

## Installation:

1. Remove the existing lens and turn signal bulb from turn signal housing. (refer to Picture 1)
2. Remove any corrosion or dielectric grease from the socket to insure the socket contacts are clean.

1




Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

## Installation Instructions - Page 2

### Installation continued:

3. Confirm the proper orientation of the socket base and insert the ProBEAM® LED turn signal base into the socket. If it seems hard to twist the base into the socket or hard to remove, it is orientated the wrong way.
4. Twist the Flat Bezel Lens a few rotations to coil wire from the ProBEAM® LED turn signal to the socket base. Shown in **Picture 2**.
5. Install the small O-rings on the mounting screws and confirm the O-ring is installed on the back side of the Flat Bezel shown in **Picture 3**.
6. Install Flat Bezel Lens onto the turn signal housing and secure with the provided screws. Shown in **Picture 4**.
7. Check operation of turn signals in all modes



**PROBEAM**<sup>®</sup>  
BY CUSTOM DYNAMICS<sup>®</sup>