



Custom Dynamics® Smart Triple Play® Installation Instructions

We thank you for purchasing the Custom Dynamics® Smart Triple Play®. Our products utilize the latest technology and high quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Number: GEN-SMART-TPU-SS8

Package Contents:

- SMART Triple Play® Module with Posi-Lock™ Connectors
- Instructions

Fits: 2010-2012 Street Glide® CVO™, 2013 Road King® CVO™, 2009 Road Glide® CVO™ and 2012-2013 Road Glide® Custom CVO™ with OEM LED Panels



Installation:

1. Secure motorcycle on level surface. Disconnect negative battery cable from the battery. Locate the lighting connector under the seat.
2. Remove the MPR-SS8-PLUG plug and play adapter for BAGZ™ and plug the Smart Triple Play® Module, in-line, into the rear lighting harness under the seat. Signal Stabilizer™ or load equalizer should be installed on the input side of the Smart Triple Play® unit (page 3).

Note: Wiring Diagram on page 3.

3. Cut and remove the 3 pin plug from each LED BAGZ™ light to expose the black, yellow, and brown (right side) or purple (left side) wires. Cap off the yellow wire from each BAGZ™ light.
4. Connect the pigtail output wires from the Smart Triple Play® using the supplied Posi-Lock™ connectors to the exposed black and brown (right side) or (left side) purple wires on the Custom Dynamics® BAGZ™ LEDs.
5. Connect the brown wire to the right side (brown) LED high wire [+]. Connect the purple wire to the left side (purple) LED high wire [+]. Connect the black wire of left side LED neg. and the right side LED neg. to the [-] black wire of the unit.
6. Re-connect the battery's negative battery cable to the battery.
7. Locate a secure place for the Smart Triple Play® unit that will not interfere with the secure placement of the seat or side cover. Secure with tie-wraps, tape or other means so that unit cannot move.
8. Program Smart Triple Play® and select desired brake strobe pattern. See Programming Instructions on page 2.
9. Test for proper run, brake and turn function.



ATTENTION



Please read all warning information before installation

Important: This system is designed to work with Custom Dynamics® BAGZ™ LED Lights. They will not work with the any Amber/ Red saddle bag lights.


Caution: This unit is designed for a maximum load of 27 watts per channel. Do not exceed 27 watts per left turn signal output, 27 watts per right turn signal output, and 27 watts per brake signal output. Overloading unit could cause damage to the unit and cause the unit to malfunction.

Important: A load equalizer or Signal Stabilizer™ is required for the Smart Triple Play® to function properly. The load equalizer MUST be installed on the input side of the Smart Triple Play® unit. NEVER install a load equalizer downstream of this unit.

Important: Dial and switches should be maneuvered by hand only. Do not use any tool such as a screwdriver that could damage waterproof covers.

Important: Module must be secured after installation. Find safe area away from any moving parts and out of the way of normal operation of the bike. Use Tie-wraps, tape, (not included) or other means to secure. Custom Dynamics® is not liable for damage to the module or the bike as a result of improperly securing the module.

EASY AS ① ② ③



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST

Installation Instructions - Page 2

Testing for Proper Operation:

1. Locate the two switches and rotary dial on the Smart Triple Play® module. Be sure the rotary dial is set to position 0. There is a small arrow on the rotary dial, this is the pointer that should now be at position 0. Be sure Switch 1 and Switch 2 are both in the ON position.
2. Turn the ignition key on and check operation as follows:
 - Running Lights: BAGZ™ Lights are now illuminated dimly.
 - Apply Right turn signal and check operation of right turn signal, should flash off to bright. Disable turn.
 - Apply Left turn signal and check operation of left turn signal, should flash off to bright. Disable turn.
 - Apply brake light. Check to see that all lights flash 4 times then remain bright.
 - Apply Left turn signal then apply brake. Check to see that only center light flashes 4 times then remains bright. If no center tail light is applicable, when the left turn signal is on and the brake is applied, the right side turn signal will stop strobing. This is normal operation.




Diagram - Module Controls

Program Mode:

1. The Smart Triple Play® allows you to program the running light brightness of the BAGZ™ Lights so they are a match to your taillights. To enter the modules program mode:
 - Turn ignition key off, be sure Switch 1 and Switch 2 are in the OFF position and the rotary dial in in the 0 position.
 - Turn ignition key on, immediately turn Switch 2 On-Off-On. Turn Switch 1 On-Off-On. Do not depress Brake or Turns Signals during this action.
 - The turn signals should now fade up and down slowly, do not proceed unless this confirmation takes place.
 - Turn the rotary dial clockwise to increase the brightness of the running lights, 0-being the dimmest setting and 9-being the brightest. Match the running light brightness to the taillight. Once happy with the setting, press and hold the brake for a couple of seconds. The setting will now be saved.
2. Turn ignition key OFF and set switches for desired Operation.

Program Menu:

Switch Functions:

Switch 1 On, Switch 2 On: Strobes/Flashes on all three Rear Lights


Switch 1 On, Switch 2 Off: Strobes/Flashes on rear turn signals only

Switch 1 Off, Switch 2 On: Strobes/Flashes on center light only


Switch 1 Off, Switch 2 Off: No Strobes/Flashes

Installation Instructions - Page 3


Flash Pattern Information:



Module Installation:



Wiring Diagram:



Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST