



Custom Dynamics® EDFR Flasher Relay Installation Instructions

We thank you for purchasing the Custom Dynamics® EDFR Flasher Relay. Our products utilize the latest technology and highest quality components to ensure you the most reliable service. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call Custom Dynamics® at 1(800) 382-1388.

Part Numbers: EDFR

Package Contents:

- EDFR Flasher Relay (1)
- Instructions

Fits: Replaces any 2 or 3 pin flasher relay on models without self-cancelling turn signals and without 4 way hazards.

Kawasaki: ZX-10R, ZX-12R, ZX-6R(R) up to 04, Z-1000, ZXR1200 (1100), ZZR1200, ZX1200, ZR-7

Suzuki: 2005 and newer S50

Yamaha: Roadstar or V-Star (Hardwire Installation Required)

Yamaha: YZF-R1, YZF-R6, YZF600, FZ-1, FJR1300

Honda: '07-'08 CBR600RR, CBR1000RR, RC-51, CBR600F4i, CB919, ST1300, GL1500, CBR1100XX, CBR900RR, CBR929RR, CBR600F2, CBR600F3, CBR600F4, VTR1000R Super Hawk, VT600, 02-04 1800 C, 02-03 1800 R models, 02-03 1800 S models, 04-05 1300 C models, 03-05 1300 S models, 05 1300 R models, 06 1300 C models. 02-08 Honda VFR



Installation:

Remove stock turn signal flasher relay.

Replace stock relay with EDFR relay.

1. Secure in place.
2. Test operation.

Hardwire Operation: (2 or 3 Pin Flasher Replacement)

1. Determine Input (constant 12V) and Output (flashing 12V) from stock turn signal flasher relay.
2. Remove stock turn signal flasher relay.
3. Cut connector off EDFR flasher relay.
4. Connect Red wire from EDFR to bike's Input (constant 12V)
5. Connect Blue wire from EDFR to bike's Output (flashing 12V). Secure in place.
6. Test operation.



ATTENTION



Please read all Information below before Installation

Warning: Disconnect negative battery cable from battery; refer to owner's manual. Failure to do so may result in electrical shock, injury, or fire. Secure negative battery cable away from positive side of battery and all other positive voltage sources on vehicle.

Safety First: Make sure the bike is parked on a level surface and bike's mechanical components are cool to the touch.

Questions? Call us at: 1 (800) 382-1388 M-TH 8:30AM-5:30PM / FR 9:30AM-5:30PM EST