
LED Turn Signals Installation Instructions



We thank you for purchasing Custom Dynamics® LED turn signals! Our Genesis™ LED's offer maintenance free service and higher visibility. We offer one of the best warranty programs in the industry and we back our products with excellent customer support, if you have questions before or during installation of this product please call **Custom Dynamics®** at 1(800)382-1388.

Installation:

1. Remove lens from turn signal housing.
2. Remove bulb from turn signal housing.
3. Be sure contacts are clean, if not scrap contacts with the end of a small flat blade screwdriver.
4. Take a small flat blade screw driver and push the edges of the black stock gasket that is around the circumference of the reflector inward to allow LED board to fully seat.
5. Insert base of LED cluster into housing, be sure it is properly oriented and fully seated.
6. Twist cluster to coil wire and insert cluster into housing.
7. While holding cluster in place, reinstall lens, push until it snaps in place.
8. For BCM bikes, run 4 ways hazards for about 3 minutes, For non BCM bike a load equalizer may be needed.
9. Check operation of turn signal in all modes.

Important Tips and Troubleshooting:

1. Dielectric grease does not need to be used with this LED product, it can actually prevent them from working. Remove any excess from your turn signal sockets before inserting.
2. Make sure you have the orientation correct before inserting the base. If it seems hard to twist in the socket, it is probably in the wrong way.
3. If you experience issues with function, clean the bottom contacts, then re-insert. Also try in the other turn signal socket.
4. If you experience fast flashing from your turn signals after installation on a non BCM Bike, you may need a load equalizer or our Signal Stabilizer. Contact us for details.
5. This LED Product is BCM Compliant. If installing on 2011 and newer Softails, 2012 and newer Dynas, or any 2014 & newer model Harley Davidson, it is recommended to run the 4 way hazards for 3 minutes to re-sync the CanBus system. No Load equalizer or Signal Stabilizer is needed for these models.

Call us at: 1 (800) 382-1388 M-TH - 8:30AM-5:30PM EST / FR - 9:30AM-5:30PM